




Turn on location and Bluetooth (Skip this step if it is on)




Click on SEPLOS Bluetooth app




Click on personal page





Click Bluetooth settings



Select the corresponding serial number



Click on the serial number, and there will be a connection until it appears that the connection is successful, and the Bluetooth APP appears with a ✓



Return to the main page to view the data in the battery and the protocol for switching the inverter.

